Before use, please read these instructions thoroughly!

Ni-MH Battery Operating Instructions



Safety Precautions

IMPORTANT: To avoid battery leaking, overheating or explosion, strictly follow these instructions! Misuse of battery may lead to leakage, heat generation or explosion. Battery becomes hot during use. Battery temperature may exceed 100C even under normal operation and may cause burns or affect the shape of some materials

↑ DANGER

- Earlure to follow instructions associated with this symbol risks injury or even death!
- Olf battery liquid enters the eye, immediately flush continuously with clear running water and consult an ophthalmologist (eve doctor). Serious and permanent eve damage may occur.

WARNING

Failure to follow instructions associated with this symbol risks injury or even death!

Prohibited

 Avoid battery liquid contact with skin and clothing. If contact occurs, remove contaminated clothing and wash skin thoroughly with water.

↑ CAUTION

●Failure to follow instructions associated with this symbol risks injury or property damage!

Before Use: Read and understand the battery and charger operating instructions before recharging.

↑ DANGER

- ONLY use Kyosho genuine charger units for recharging Kyosho brand Ni-MH batteries
- Ensure polarity is correct when plugging a battery into the charger unit.
- NEVER plug a battery directly into household outlets or cigarette lighters in cars!



↑ WARNING

- NEVER put a battery into water or seawater!
- Make sure to charge a new or disused battery before use.
- If you find an irregular noise, temperature. or any leaking from your battery, stop using it immediately

♠CAUTION

 Before using a battery. ALWAYS read the explanations attached

Keep battery away from exposed flame, high temperatures and humidity.

During use: Always monitor a battery while it's charging so you can react to any unexpected problems.

A DANGER

- Kvosho batteries are ONLY for use in B/C (radio control) models! Do NOT use them for any other purpose!
- NEVER disassemble or modify a battery!



↑ WARNING

- Do NOT remove or cut the outer tubing from a battery!
- Discontinue charging immediately if the charge time has been exceeded, even if the battery is not fully charged.

⚠CAUTION

- Keep and use batteries ONLY in places out of reach of children!
- When battery is hot. do not touch it, and handle only after it has cooled down.

After use: Remove battery from the R/C model when not in use.

DANGER

 NEVER dispose of a battery into a fire or allow it to heat up!



WARNING

- Do NOT recharge or use a battery while it is still hot!
 - If the battery is delivering less power. stop your model and discharge the battery.



battery, ALWAYS unplug and remove it from the R/C model!

USE (For charging, please refer to instruction manual of the charger unit!)

Ensure the speed controller is in neutral (the electric motor is not running)

from the tires (with cars) or the propeller (with airplanes) or rotor (with helicopter) to prevent hurting yourself if the motor should start rotating unexpectedly!



Confirm connector polarity.


then plug the battery gently into your R/C model.

Unplug and remove the battery from your R/C model after every use or when not operating it!



Unplug the battery by holding the connector itself and NOT by pulling at its

be hot. Before recharging it, it must be cooled for at least 1 hour in a well ventilated place



over if it produces only short running times even if was correctly recharged to full capacity. A battery is recyclable. At the end of its useful life, under various national, state or local

